

A. Normal Operation
FP = Cycle LCD Screen Forward
SP = Turn **LOGGER DATA RECORD ON or OFF**

B. Setup Mode
FP = Cycle Setup Menu Screens Forward (NEXT)

**SETUP MODE - Press BOTH
LCD Select Buttons Simultaneously
to ENTER & EXIT Setup Mode**

A. Normal Operation
FP = Cycle LCD Screen Back
SP = Reset LCD Menu Screen on view

B. Setup Mode
FP = EDIT Setup Screen | Increase Value(ADD)

A. Normal Operation
FP = Cycle LED Screen Forward

B. Setup Mode
FP = Cycle LCD Setup Menu Screens Back

A. Normal Operation
FP = Cycle LED Screen Back

B. Setup Mode
FP = Decrease Setup Value



A. Normal Operation
FP = Manual Start | Stop Lap Time (Stopwatch Mode)
SP = ARM Lap Timer

(NOTE - For Manual Lap Timing, Lap Blank Period MUST be set to 0 (Zero) Seconds.)

DD2-SS Button Function Summary

FP = Fast Press
SP = Press & Hold for 2 Seconds